



Pour accéder aux paramètres de votre Hotspot ORA, rentrez l'adresse suivante dans votre navigateur internet : <http://192.168.0.1/>

Internet	Router	Home Network
Cellular Connection Signal Strength: Cellular Data Connectivity: Enabled Disabled	Router Information Router LAN IP: 192.168.0.1 IMEI: 863779022794940 Router Network Mask: 255.255.255.0 Router MAC: 34:ba:9a:00:b7:82 Run Time: 0 Day 0 Hour 1 Minute 52 Seconds Battery Charging: Charging Battery Electric Quantity:	Connected Devices 1
Internet Connection Network Operator: Viti Cellular Network Mode: LTE PDP Information PDN1 PDP Type: Default Primary PDP PDP Connection Status: connected IPv4 Address: 103.4.73.161 IPv4 DNS Server: 113.197.68.2, 113.197.68.3 IPv4 Default Gateway: 103.4.73.94 IPv4 Network Mask:	Wireless Enabled	Wireless Settings Wireless Network: GP-WIFI-1-B782 Security Mode: WPA-WPA2 Mixed Channel Number: Automatic
	Software Information Device Mode: MIFI Software Version: NZ_MF_M894_GP1.16_V08 Hardware Version: NZ_SSG_V20 Serial Number:	DHCP Server Enabled
		Traffic Statistics Sent Packets: 137992 Received Packets: 185391 Reset

[Texte]

➤ Accès admin

Pour accéder aux autres onglets, il vous sera demandé de vous identifier. Le nom d'utilisateur et le mot de passe par défaut est : **admin / admin**

➤ Changement des paramètres Wifi

Pour changer les Paramètres Wifi, allez dans l'onglet **Wireless**. Dans la colonne de gauche cliquez sur **Wireless Security**. Modifiez vos paramètres Wifi comme vous le souhaitez puis cliquez sur **Save** pour valider les modifications.

Le premier champ, SSID correspond au nom de votre réseau Wifi
 Vous pouvez changer votre mot de passe wifi dans le champ **Password**